




# NOZZLES/MONITORS

## HOSE REEL ASSEMBLY



MODEL NO.	A	B	C	D	E	F	G	J	K
BFHR - 50	24 (610)	19 (483)	26 (660)	10 (254)	10 (254)	16 (406)	21 (533)	14-3/4 (375)	17 (432)
BFHR - 100	24 (610)	19 (483)	26 (660)	20 (508)	10 (254)	26 (660)	31 (787)	24 3/4 (629)	17 (432)
BFHR - 125	29 (737)	24 (610)	31 (787)	20 (508)	10 (254)	26 (660)	31 (787)	24 3/4 (629)	22 (559)
BFHR - 150	29 (737)	24 (610)	31 (787)	20 (508)	10 (254)	26 (660)	31 (787)	24 3/4 (629)	22 (559)
BFHR - 175	29 (737)	24 (610)	31 (787)	20 (508)	10 (254)	26 (660)	31 (787)	24 3/4 (629)	22 (559)
BFHR - 200	29 (737)	24 (610)	31 (787)	20 (508)	10 (254)	26 (660)	31 (787)	24 3/4 (629)	22 (559)

